


1
L-shaped
side panel



2 PCS

2
Side panel




2 PCS

3
Long scratching
board



1 PC

4
Short scratching
board



1 PC

5
Play ball







1 PC

6
Screws



14 PCS






Step 1
Align the L-shaped side panel (1) on the short scratching board (4) and secure it with 2 screws (6).

Step 2
Repeat this on the other side.

Step 3
Attach the side panel (2) to the L-shaped side panel (1). Align the long scratching board (3). Do not tighten the screws yet.

Step 4
Place the play ball (5) in the track and adjust the position of the long scratching board (3) so that it cannot fall out.



Step 5
After adjustment, screw in 5 screws (6).

Step 6
Turn the scratching board and attach the second side panel (2) to the scratching board using 5 screws.

Step 7
Done! You can add the play-stimulating catnip and silvervine granulate for an extra dose of playtime fun.